

INSTRUCTIONS FOR FITTING F360 REAR GRILLE

There are no additional fittings required for your new F360 Rear Grille. It utilizes the exact same fittings and fasteners as your current grille.

Tools required : ¼" drive socket wrench set (metric)

The picture below shows location of 12 fastening points for removing grille.



Open engine lid.

Disconnect tail lights and turn signal lights from wiring loom.

Remove tail lights and turn signal lights from grille, being careful to retrieve nuts and washers. Removing lights first provides easier access to nuts securing grille. When dismantling, take note of the location of wiring loom and cable retaining brackets for re-attachment.

Remove remainder of nuts holding grille, again taking care to retrieve nuts and washers. A little blu-tack on socket can assist in retrieving nuts. Dropped nuts and washers will add an hour to your installation time, as you will need to remove the rear under body panel to retrieve them.

Making sure you have undone all fastening points, the grille panel should just slide out.

Remove the Cavallino badge from your old grille and fit to new panel.

Reverse procedure to fit new grille.

When reinstalling your grille and lights be careful not to over tighten any of the nuts, a firm hand tight is sufficient.

When finished, use a rag to wipe off all your dirty fingermarks, stand back and admire your *new look* Ferrari F360

CONGRATULATIONS ON A SUCCESSFUL INSTALLATION.



IMPORTANT: If you feel uncertain about your ability to carry out the installation yourself, **DO NOT** risk damaging your car or the product. Your mechanic can do the job in about 1 hour. Good luck and enjoy your *new look* Ferrari F360.